


KUKJE BACKHOE(BH76D) Branson Backhoe

Parts Catalogue



BRANSON TRACTOR

FIG A01D


Year/Month

BACKHOE(BH76D)

1. Assembly - BH76E

2020/02

ASSEMBLY



BH76D

BH76D-PM-D01

FIG A02

2. Main Frame Assembly

Year/Month

BACKHOE(BH76D)

2020/02




FIG A03 BACKHOE(BH76D)	3. Mounting kit Assembly	Year/Month 2020/02
---------------------------	--------------------------	-----------------------




FIG A04


BACKHOE(BH76D)

4. Swing Frame Assembly

Year/Month

2020/02

SWING FRAME ASSEMBLY



BSF4A

BSF4A-SF-001

FIG A05


5. Boom Lower Assembly

Year/Month

BACKHOE(BH76D)

2020/02

BOOM LOWER ASSEMBLY



BBL76C

BBL76C-BL-001

FIG A06


BACKHOE(BH76D)

6. Boom High Assembly

Year/Month

2020/02

BOOM HIGH ASSEMBLY



BBH76C

BBH76C-BH-DD1

FIG A07D


7. Bucket Assembly - BH76D

Year/Month

BACKHOE(BH76D)

2020/02

BUCKET ASSEMBLY



BEK408

BEK408-BK-002

FIG A08.1

BACKHOE(BH76D)

8. Cylinder Assembly(P/N: BH76C-09-8100)

Year/Month

2020/02




FIG A08.2
BACKHOE(BH76D)

8. Cylinder Assembly(P/N: BH76C-09-830A)

Year/Month
2020/02




FIG A08.3
BACKHOE(BH76D)

8. Cylinder Assembly(P/N:BMF4025B-8500)

Year/Month
2020/02




FIG A08.4


BACKHOE(BH76D)

8. Cylinder Assembly(P/N: BH76C-09-9000)

Year/Month

2020/02

CYLINDER ASSEMBLY



BH76C-09-9000

BH76C-09-9000-D01

FIG A08.5
BACKHOE(BH76D)

8. Cylinder Assembly(P/N: BH66A-09-950D)

Year/Month
2020/02




FIG A09

BACKHOE(BH76D)

9. HYDRAULIC PARTS

Year/Month

2020/02




FIG A10
BACKHOE(BH76D)

10. Decal & Manual

Year/Month
2020/02

