

KUKJE BL20ASL Branson Loader

Parts Catalogue

FIG 001

ASL LOADER BOOM AND BUCKET PAGE.
WPC ISSUE

Year/Month

BL20ASL

2020/02





FIG 008

MOUNTING KIT

Year/Month

BL20ASL

2020/02



000001

FIG 011

HYDRAULIC PARTS

Year/Month

BL20ASL

2020/02




FIG 014

BL20ASL

CYLINDER

Year/Month

2020/02




FIG 016

ATTACHMENT

Year/Month

BL20ASL

2020/02




FIG 017

BUCKET

Year/Month

BL20ASL

2020/02





FIG 018

DECAL AND MANUAL




Year/Month

BL20ASL

2020/02



RH.



LH.

FIG 019

CONTROL VALVE SPARE PART

Year/Month

BL20ASL

2020/02

